



SECTION SHOWING DETAILS OF CORRECTIVE MEASURES FOR OMITTED VERTICAL REBAR AT SHEARWALL HOLDOWN POINTS

$\frac{3}{4}'' = 1'-0''$

NOTE: VERTICAL ANGLE ASSEMBLY SHOWN IS TO BE INSTALLED AT EACH HOLDOWN POINT AT ENDS OF EACH SHEARWALL SW1 AND SW2. PRIOR TO INSTALLATION, ANGLES ARE TO BE PAINTED WITH 2 COATS OF ASPHALTIC PAINT ON ALL SURFACES. AFTER INSTALLATION, ALL SURFACES OF ANCHORS ARE TO BE PAINTED WITH 2 COATS OF ASPHALTIC PAINT.